


S500说明书V1.2

规格：65X100MM 4折页8P
材质：100克书纸


Android TV™ Box

Quick Start Guide




HiMedia Technology Limited
www.himediatech.com

Interface



Bluetooth Remote Controller




Item	Button	Description
1		POWER ON/OFF
2		DIRECTION
3		OK
4		RETURN
5		HOME
6		VOLUME DOWN
7		GOOGLE ASSISTANT
8		VOLUME UP
9		START YOUTUBE
10		START GOOGLE PLAY

Google, Google Play, YouTube, Android TV, Chromecast and other related marks and logos are trademarks of Google LLC.


Connect to TV

Connect one end of the HDMI Cable provided into the HDMI Port on the back panel of your TV Box, while connecting the other end of the HDMI Cable to an HDMI Port on the TV.




TV Input

Press the **INPUT** or **SOURCE** button on your TV Remote to access the TV's input selection menu.



Bluetooth Remote Connection

Place the Bluetooth Remote within 30cm of the TV Box. Then press and hold both the **RETURN** and **HOME** buttons simultaneously, until the LED Indicator flashes quickly. This indicates the Bluetooth Remote has entered 'pairing mode'.



Connect to a Network

Refer to **Home\Settings\Network & Internet\WiFi** to enable Wireless Network and setup a connection to your local WiFi.

