



Smart Pet Fountain




Quick Guide User Manual

V1.0


Content

Please read this manual carefully before operation to ensure safe usage of the pet fountain. This instruction manual is suitable for the multi-function version and the basic version of pet fountain, the basic version will not be introduced repeatedly.




Pet Fountain (subject to the actual product)

List of accessories (subject to the actual product)



Adapter X1



Anti-break bite power cord X1




User manual

Product description.....2
 Operation guide.....3-6
 First usage.....3
 Binding smart life app.....3-5
 Pet Fountain APP interface introduction.....6
 Schematic diagram of water supply after pet fountain lacks water.....7
 Cleaning diagram.....8
 Precautions.....9
 FAQ.....11

product introduction

Structure introduction



Operation guide

1. First usage

1. Please take out pet fountain and accessories
2. Please clean inner wall and top cover of water storage bucket and filter core
3. please insert filter core into the filter core slot at the bottom of the top cover after immersing the filter element in clean water for 2 minutes,
4. Please add water to the transparent water bucket above the MIN line and below the MAX line.
5. Please take the adapter and plug it into the USB interface of the button of pet fountain
6. Please press the button on the front body of pet fountain to turn on and off the water feeding function, and please press the button for long time (around 6 to 7 seconds) to restore factory default settings, it will come to network configuration status (network indicator flashes)

2. Binding Smart Life APP



2.1: APP download and installation

Please scan the QR code below or QR code on the packing box to download Smart Life app and complete the installation




2.2: App Registration


1. APP Please open "Smart Life" APP
2. Please click "create new account"
3. Please select the time zone to input the account to get verification code
4. Please input the received verification code for verification
5. Please set up login password and login successfully.




3.3: Pet Fountain Configuration



1. Please log in APP to add device
2. Click "Pet Fountain"
3. Confirm indicator rapidly blink
4. Enter Wi-Fi Password
5. Connecting....
6. Device added successfully




三、Pet Fountain Interface Introduction



Pet Fountain Interface Introduction

1. Setting : other function
2. Switch
3. Switch
4. Timing
5. Disinfect



Setting


1. Device Name
2. Device Information
3. ap-to-Run and Automation
4. Offline Notification
5. Share Device
6. FAQ & Feedback
7. Add to Home Screen
8. Check Device Network

- 1) .Remove
- 2) .Reset


6

Adding Water Instruction


APP alarm push for lowest water level




1. No need to power off, just take out the water tank and cover



2. No need to power off, just take out the water tank and cover



3. Add water till up to MAX level on the water tank
Warning: Hot Water Forbidden




4. Put the top cover and put the water tank back


7

Clean Instruction


Recommended to clean at least once per week and change water to prevent poor water quality or poor outlet water caused by filtration blockage.




1. Remove the water tank cover and clean




2. Remove the filter and groove carefully




3. Clean the filter groove and remove dirties



4. Clean the pump



5. Clean inside of the water tank and dry outside



6. When the filter slot is replaced by the top cover, check whether the bayonet is closed.

8

Attention

1. Be sure to clean the power after disconnecting the power supply.
2. Do not immerse the pet fountain body and power adapter in water.
3. For the first time, please clean the inside of the transparent water tank, top cover and the filter slot.
4. The filter may be attached with a small amount of powder. This is a normal phenomenon. Rinse.
5. The filter is recommended to be replaced once a month.

Warning

1. Pet fountain and all accessories are not edible.
2. Please use pet fountain in a dry indoor environment.
3. Do not place pet fountain in a high place.
4. Keep the pet fountain horizontal when using it. Do not tilt or tip it.
5. Do not add hot water or boiling water in the water tank to avoid hot deformation.
6. Please make sure that the power cable is blocked and stored to avoid leakage damage caused by pet bites. The power supply is in safe working voltage, does not endanger the safety of pets and owners.
7. Do not disassemble or repair the pet fountain, otherwise affecting the after-sales.
8. Please do not use any accessories that are not provided by the original manufacturer. We are only responsible for the performance and safety of the officially designated accessories.

9

FAQ

Q. How often does pet fountain change the water and how often we need to clean it?
 A. According to the water quality and pet drinking habits. It is recommended to replace or add water every 2-3 days; it is recommended to clean at least once a week (including water tank, top cover, filter slot, filter), and completely change the water to prevent fouling from clogging the filter slot, resulting in abnormal water quality.
 Do not use hot water or boiling water when cleaning.

Q. What kinds of water should be used in the pet fountain?
 A. It is recommended to use pure water or mineral water.

Q. How often does filter need to be replaced?
 A. The filter is recommended to be replaced once a month to maintain a good filter effect.

Q. Does the pet fountain consume lots of power? is there any noise?
 A. It has low working power (MAX4.5W) and consumes about 1 kWh in 10 days. The product adopts silent pump and noise reduction design, working without noise. (There is natural water sounds to attract pets to drink plenty of water.)

Q. Is there any safety hazard when the power cable of the pet fountain is bitten by a pet?
 A. The power supply adopts 5V low voltage and 0.6A low current to ensure the safety of pets. Friendly reminder: use broken power cable will have a hazards of pets eating, please replace it in time.

Q. What are the most suitable cats and dogs for pet fountain?
 A. Suitable for adult cats and small and medium dogs.

Q: What is the reason that the pet fountain does not work after it is powered on?

10

EU Simplified Declaration of Conformity
 SC ONLINESHOP SRL declares that **Smart pet water feeder PNI MyPet PT022WF** complies with the Directive EMC 2014/30/EU and RED 2014/53/UE. The full text of the EU declaration of conformity is available at the following Internet address:
<https://www.mypni.eu/products/7292/download/certifications>




Manual de utilizare Hranitoare inteligenta de apa PNI MyPet PT022WF



Continut

Inainte de a utiliza produsul va rugam cititi manualul cu atentie.




Hranitoare
inteligenta

Continut pachet



Adaptor x1




Cablu alimentare x1



Manual de utilizare

| | |
|---------------------------------------|-----|
| Descrierea produsului..... | 2 |
| Ghidul de operare..... | 3-6 |
| Prima utilizare..... | 3 |
| Instalare aplicatie..... | 3-5 |
| Prezentare interfata aplicatie..... | 6 |
| Instructiuni pentru adaugare apa..... | 7 |
| Procedura curatare hranitoare..... | 8 |
| Atentionari..... | 9 |
| FAQ..... | 11 |

Prezentarea produsului



Ghid de operare

1. Prima utilizare

- 1.1 Scoateti produsul si toate accesoriile
- 1.2 Va rugam sa curatati peretii interiori, capacul rezervorului de apa si filtrul.
- 1.3 Introduceti filtrul in fanta din partea de jos a capacului dupa ce ati lasat filtrul in apa curata timp de 2 minute.
- 1.4 Aduagati apa in rezervor deasupra liniei MIN si sub linia MAX.
- 1.5 Alimentati hranitoarea.
- 1.6 Apasati butonul ON de pe panoul frontal pentru a porni hranitoarea apoi tineti apasat butonul ON timp de 6 - 7 secunde pentru a restabili setarile implicite din fabrica, va deschide setarea configurarii de retea (indicatorul LED al retelei va clipi)

2. Instalarea aplicatiei



2.1 Descarcati aplicatia

Scanati codul QR de mai jos sau codul QR de pe cutia produsului pentru a descarca aplicatia si a finaliza instalarea.




2.2 Aduagare hranitoare in aplicatia Tuya


1. Deschideti aplicatia .
2. Creati cont .
3. Pentru a primi codul de verificare selectati "time zone"
4. Introduceti codul de verificare primit.
5. Setati parola.




3.3 Configurare hranitoare



1. Autentificati-va
2. Faceti click pe "Pet Fountain"
3. Pentru confirmare ledul va clipi
4. Introduceti parola Wi-Fi
5. Conectare..
6. Dispozitivul a fost adaugat




Prezentare interfata hranitoare



Prezentare interfata hranitoare

1. Setari: alte functii
2. Comutator
3. Comutator
4. Sincronizare
5. Curatare



Setari:


1. Nume dispozitiv
2. Informatii dispozitiv
3. Apasati pentru pornire si automatizare
4. Notificari offline
5. Distribuire dispozitiv
6. FAQ si pareri
7. Cautare retea
8. Cautare actualizare firmware

- (1) Stergere
- (2) Resetare


6

Instructiuni adaugare apa


Alarma pentru nivel de apa scazut



1. Nu este nevoie sa opriti alimentarea, doar scoateti rezervorul de apa




2. Nu este nevoie sa opriti alimentarea, doar scoateti capacul



3. Aduagati apa pana la indicatorul MAX de pe rezervor

Atentie: Nu adaugati apa fierbinte




4. Puneti capacul si introduceti rezervorul inapoi in hranitoare


7

Instructiuni de curatare


Se recomanda sa curatati rezervorul si sa inlocuiti apa macar o data pe saptamana pentru a preveni o calitate slaba a apei.




1. Indepartati si curatati capacul rezervorului




2. Indepartati filtrul si curatati-l cu atentie




3. Curatati filtrul si indepartati depunerile



4. Curatati pompa



5. Curatati interiorul rezervorului



6. Cand puneti filtrul in fanta verificati sa fie bine inchisa

8

Atentionari

1. Inainte de a curata dispozitivul, deconectati-l de la sursa de curent.
2. Nu scufundati in apa hranitoare sau adaptorul de alimentare.
3. Inainte de prima utilizare, curatati interiorul rezervorului de apa, capacul si fanta pentru filtru.
4. Este posibil ca filtrul sa fie fixat cu o cantitate mica de pudra. Este normal. Clatiti inainte de prima utilizare.
5. Este recomandata inlocuirea filtrului o data pe luna.

Avertizari

1. Hranitoare sau accesoriile nu sunt comestibile.
2. Folositi hranitoare intr-un mediu interior uscat.
3. Nu asezati hranitoare intr-un loc inalt.
4. Tineti produsul pe nivel orizontal. Nu il inclinati sau rasturnati.
5. Nu adaugati apa fierbinte in rezervor pentru a evita deformarea.
6. Cablul de alimentare trebuie depozitat pentru a evita deteriorarea lui cauzata de muscaturile animalelor.
7. Nu incercati sa dezamblati sau reparati produsul.
8. Nu folositi alte accesorii decat cele furnizate de producator. Producatorul este singurul responsabil de performanta si siguranta accesoriilor.

9

FAQ

Q. Cat de des trebuie curatata hranitoare si la cat timp se schimba apa?
A. In conformitate cu calitatea apei si cu obiceiurile animalului de companie. Se recomanda a se schimba apa o data la 2-3 zile; Se recomanda a se curata recipientul cel putin o data pe saptamana (inclusiv rezervorul de apa, capacul, fanta filtrului si filtrul) si schimbarea completa a apei pentru a preveni infundarea filtrului. Nu folositi apa fierbinte la curatarea produsului.

Q. Ce fel de apa trebuie folosita?

A. Se recomanda folosirea apei filtrate sau a apei minerale.

Q. La cat timp se schimba filtrul?

A. Pentru a pastra calitatea filtrului, se recomanda inlocuirea lui o data pe luna.

Q. Hranitoare consuma mult curent? Este zgomotoasa?

A. Are un consum scazut (MAX 4.5W) si consuma aproximativ 1 kWh in 10 zile. Produsul beneficiaza de o pompa silentioasa si de un design care reduce zgomotul. (Are un sunet natural pentru a atrage animalele de companie sa bea suficienta apa).

Q. Este un pericol daca animalul de companie musca din cablul de alimentare?

A. Alimentarea are o tensiune de 5V / 0.6A pentru siguranta animalelor de companie. Friendly reminder: nu folositi cablul de alimentare deteriorat, va rugam sa il inlocuiti in cel mai scurt timp posibil.

Q. Care sunt cele mai potrivite animale de companie pentru a folosi acest produs?

A. Produsul este potrivit pentru pisici si caini de talie mica si medie.

Declaratie UE de conformitate simplificata
SC ONLINESHOP SRL declara ca **Hranitoare inteligenta de apa PNI MyPet PT022WF** este in conformitate cu Directiva EMC 2014/30/EU si RED 2014/53/UE. Textul integral al declaratiei UE de conformitate este disponibil la urmatoarea adresa de internet:
<https://www.mypni.eu/products/7292/download/certifications>